

YOUR GUIDE

Controlled Receptacle Operation

This room is equipped with energy-saving Automatic Receptacle Controls that automatically turn on when the room is occupied and turn off after the room is vacated. This turns power on and off to equipment plugged into these marked receptacles. Identifying

which receptacles automatically turn on/off and which remain constantly powered is essential.

Follow these guidelines to plug the correct equipment into the appropriate receptacle.


Identification Markings

Controlled Receptacle

Marked "CONTROLLED" and with ⏻ symbol -this receptacle automatically turns on/off by schedule or as people enter and leave the local area

Constant Power Receptacle

No Markings - this receptacle is not controlled; power constantly remains on.



What Equipment to Plug In:

Controlled Receptacle

- Displays/monitors
- Task or exam lights
- Space heaters
- Fans
- Radios/speakers
- Printers
- Hot plates
- Kitchen equipment
- Exercise equipment
- Televisions
- Cable and satellite boxes

Constant Power Receptacle

- Computer CPUs
- Ethernet switches or routers
- Devices that must always be on or powered

The example shown is with a controlled on/off receptacle on the top (observe markings), and a constant power receptacle on the bottom (no markings).